


# ELECTRONIC CONTROL SYSTEM

With Immobilizer Control System



	Wire color	
1. ATS	B/Bl ... Black/Blue	Lg/B ... Lightgreen/Black
2. ECT	B/G ... Black/Green	Lg/R ... Lightgreen/Red
3. "CHECK ENGINE" light	B/R ... Black/Red	Lg/W... Lightgreen/White
4. Pressure sensor	B/W ... Black/White	Lg/Y ... Lightgreen/Yellow
5. TP Sensor	B/Y ... Black/Yellow	O ..... Orange
6. Heated oxygen sensor	Bl ..... Blue	P ..... Pink
7. Ignitor (Power unit)	Bl/B ... Blue/Black	P/B ... Pink/Black
8. Ignition coil	Bl/G ... Blue/Green	R ..... Red
9. Noise suppressor	Bl/R ... Blue/Red	R/B ... Red/Black
10. Blank	Bl/W ... Blue/White	R/G ... Red/Green
11. VSS	Bl/Y ... Blue/Yellow	R/Y ... Red/Yellow
12. CMP Sensor (in distributor)	Bl/O ... Blue/Orange	R/Bl ... Red/Blue
13. Power steering pressure switch (if equipped)	Br ..... Brown	Sb ..... Skyblue
14. Monitor coupler	Br/B ... Brown/Black	V ..... Violet
15. Diag. switch terminal	Br/Y ... Brown/Yellow	V/Y ... Violet/Yellow
16. ECM	Gr ..... Gray	W ..... White
17. Blank	Gr/G... Gray/Green	W/Y ... White/Yellow
18. Blank	Gr/R ... Gray/Red	Y ..... Yellow
19. Heated oxygen sensor heater relay	Gr/Y ... Gray/Yellow	Y/B ... Yellow/Black
	Lg ..... Lightgreen	

20. Starter magnetic switch
21. Serial data terminal (DLC)
22. A/C amplifier (if equipped)
23. Blank
24. Main relay
25. Fuel pump
26. Fuel pump relay
27. EVAP canister purge valve
28. EGR vacuum switching valve
29. Throttle opener vacuum switching valve
30. IAC valve
31. Fuel injector
32. To fuses  
The wire No. s are same No. as figure of POWER SUPPLY DIAGRAM (Refer to SECTION 8).
33. EGR valve (stepper motor)
34. To tachometer